

SERVICE NOTICE

SUBJECT: Garmin Electronic Checklist Update
EFFECTIVITY: 100-0001 through 100-0079

BACKGROUND

This Service Notice is to make customers aware of an available update to the Garmin Electronic Checklist for aircraft not equipped with floats. In order to maximize the usability and effectiveness of the Garmin Electronic Checklist, QUEST® Aircraft has reorganized and updated the information contained within the checklist. In order to obtain the new Garmin Electronic Checklist, contact QUEST® Customer Service.

DISCUSSION

Revision 00 of the Garmin Electronic Checklist (P/N GEC-AM901.0) updates the following:

- Checklist items covering optional features were removed in order to establish a “base” checklist suitable for all aircraft not equipped with floats.
- Checklist organization was updated
- Checklist structure was updated to best utilize the electronic format
- Checklist items were streamlined to increase clarity

INSTRUCTIONS

▲ NOTE ▲

Use caution when working with the files on the SD card. The SD card has many files and folders on it that pertain to the G1000 databases, which can be damaged if accidental deletions or renaming occurs.

1. Remove the lower SD card located in the Multi-Function Flight Display (MFD).
2. Connect the SD card to an SD card reader connected to a PC.
3. Replace the file named *chklist.ace* located on the SD card with the new file *chklist.ace* provided from QUEST® Aircraft Company.
4. Reinstall the SD card into the lower SD card slot in the MFD.
5. Verify that the correct revision of the Garmin Electronic Checklist has been installed on the aircraft by opening the checklist and viewing the revision and effective date as shown in **Figure 1-1**.

Revision Level and Effective Date →




Figure 1-1: Garmin Electronic Checklist Information Screen